

Waste Water Recycling Systems Domino WWR - Micro



PUBLICATION DATE JULY 2018

www.everythingwater.com

7 Unley Street, Brendale QLD 4500. Australia Tel: +61 7 3889 8546 Fax: +61 7 3889 6057



Waste Water Recycling Systems Domino WWR Micro

Overview


The Domino WWR-Micro Is an afordable entry level waste water recycler. The Micro is ideal for use in many industrial applications. The Micro uses a combination of an ICSEP and bag filtration technology to achieve particulate removal down to 5 micron level.

Applications

- Truck & machinery wash water reclaim.
- Hose down areas in factories, workshops and maintenance centres.
- Power Stations, Mine Sites, Refineries and petrochemical plants.
- Oil Tank Farms and Fuel Depots.

Features

- Filtration down to 5 micron removes most hydrocarbons & dirts etc.
- Recycled water suitable for use with hand held pressure washers
- Very low chemical requirments compared to competitor solutions. Save up to 80% on chemical costs.
- Easy maintenance, low cost bag filtration system.
- Scalable. Base unit can process up to 3000l/hour easy upgrade to 6, 9 or 12000l/h




Everything Water Australia Pty Ltd ABN: 64 163 322 772 Tel: 1300 368 108 Fax: +61 7 3889 6057 www.everythingwater.com admin@everythingwater.com





Domino WWR Micro

Domino WWR-Micro Process Diagram




Everything Water Australia Pty Ltd ABN: 64 163 322 772Tel: 1300 368 108Fax: +61 7 3889 6057www.everythingwater.comadmin@everythingwater.com



Domino WWR Micro

Typical Domino WWR-Micro Installation



How it works

- 1. Waste water enters the system through the silt and solids trap.
- 2. As the solids trap fills water weirs over into the settlement tank.
- 3. The settlement tank fills until it also weirs into the primary treatment tank.
- 4. The water in the primary treatment tank is simultaneously treated in 2 ways:
- a. Oily water is drawn from the surface of the tank by a floating skimmer which is then fed through a vertical gravity separator (VGS) before returning to the primary treatment tank. Oils and floating solids are captured in the VGS for later disposal.
- b. Cleaner water is simultaneously drawn from the middle of the tank into the ICSEP where

a flocculent is added and the induced cyclonic air infusion process is commenced before transfer of the water into the liquid separation vessel (LSV).

- 5. The surface of the water in the LSV is "scraped" to remove suspended solids and oils displaced by the ICSEP. Clean water is drawn off into the pre-filltration holding tank.
- 6. Water from the pre-filtration holding tank is pumped through a pair of bag filters removing contaminants down to 5 micron.
- 7. Clean water ready for use is stored in the recycled water holding tank.
- 8. Water in the recycled water tank is monitored and dosed with chlorine to maintain water quality and ensure OHS requirements are met.


Everything Water Australia Pty Ltd ABN: 64 163 322 772 Tel: 1300 368 108 Fax: +61 7 3889 6057 www.everythingwater.com admin@everythingwater.com





Domino WWR Micro

Typical Domino WWR-Micro Installation



Suitable Bunding around WWR unit

> Everything Water Australia Pty Ltd ABN: 64 163 322 772 Tel: 1300 368 108 Fax: +61 7 3889 6057 www.everythingwater.com admin@everythingwater.com

