DRAWING No	DESCRIPTION
FS00-1-1.1	TABLE OF CONTENTS - PART 1
FS00-1-1.2	TABLE OF CONTENTS - PART 2
FS00-1-2	STANDARD LOGIC SYSTEMS DIRECTIONS FOR USE AND STANDARD I/O BLOCKS LIST
FS00-1-3.1	STANDARD LOGIC DIAGRAMS BUSES LINKING MODULES - SORTED BY SOURCE CODE - PART 1
FS00-1-3.2	STANDARD LOGIC DIAGRAMS BUSES LINKING MODULES - SORTED BY SOURCE CODE - PART 2
FS00-1-4.1	STANDARD LOGIC DIAGRAMS BUSES LINKING MODULES - SORTED BY DESTINATION CODE - PART 1
FS00-1-4.2	STANDARD LOGIC DIAGRAMS BUSES LINKING MODULES - SORTED BY DESTINATION CODE - PART 2
FS00-1-5.1	STANDARD LOGIC DIAGRAMS BUSES LINKING MODULES - SORTED BY BUS NAME - PART 1
FS00-1-5.2	STANDARD LOGIC DIAGRAMS BUSES LINKING MODULES - SORTED BY BUS NAME - PART 2
FS00-2-1.1	STANDARD LOGIC DIAGRAM STATION STATUS MODULE - PART 1
FS00-2-1.2	STANDARD LOGIC DIAGRAM STATION STATUS MODULE - PART 2
FS00-2-2	STANDARD LOGIC DIAGRAM STATION INHIBIT MODULE
FS00-2-3.1	STANDARD LOGIC DIAGRAM UNIT STOP/START MODULE - PART 1
FS00-2-3.2	STANDARD LOGIC DIAGRAM UNIT STOP/START MODULE - PART 2
FS00-2-4.1	STANDARD LOGIC DIAGRAM UNIT STATUS MODULE - PART 1
FS00-2-4.2	STANDARD LOGIC DIAGRAM UNIT STATUS MODULE - PART 2
FS00-2-5.1	STANDARD LOGIC DIAGRAM UNIT ELECTRICAL AND HYDRAULIC FAULT MODULE - PART 1
FS00-2-5.2	STANDARD LOGIC DIAGRAM UNIT ELECTRICAL AND HYDRAULIC FAULT MODULE - PART 2
FS00-2-6.1	STANDARD LOGIC DIAGRAM UNIT BEARING FAULT MODULE - PART 1
FS00-2-6.2	STANDARD LOGIC DIAGRAM UNIT BEARING FAULT MODULE - PART 2
FS00-2-7	STANDARD LOGIC DIAGRAM UNIT AUXILIARIES MODULE
FS00-2-8.1	STANDARD LOGIC DIAGRAM SURGE VESSEL MODULE - PART 1
FS00-2-8.2	STANDARD LOGIC DIAGRAM SURGE VESSEL MODULE - PART 2
FS00-2-9.1	STANDARD LOGIC DIAGRAM TRANSFORMER MODULE - PART 1
FS00-2-9.2	STANDARD LOGIC DIAGRAM TRANSFORMER MODULE - PART 2

DRAWING No	DESCRIPTION
FS00-2-10	STANDARD LOGIC DIAGRAM STATION ANALOGUES AND TOTALISERS MODULE
FS00-2-11	STANDARD LOGIC DIAGRAM UNIT ANALOGUES AND TOTALISERS MODULE
FS00-2-12	STANDARD LOGIC DIAGRAM UNIT VIBRATION MODULE
FS00-2-13	STANDARD LOGIC DIAGRAM UNIT * BORE STATUS MODULE
FS00-2-14	STANDARD LOGIC DIAGRAM BORE ANALOGUE MODULE
FS00-2-15.1	STANDARD LOGIC DIAGRAM SINGLE DUTY MODULE - PART 1
FS00-2-15.2	STANDARD LOGIC DIAGRAM SINGLE DUTY MODULE - PART 2
FS00-2-16	STANDARD LOGIC DIAGRAM ABB VSC ACS1000 STOP/START MODULE
FS00-2-17	STANDARD LOGIC DIAGRAM ABB VSC ACS1000 I/O CONNECTIONS
FS00-3-1.1	TYPICAL THREE UNIT REMOTE CONTROL PUMP STATION LOGIC DIAGRAM MODULE CONNECTIONS - PART 1
FS00-3-1.2	TYPICAL THREE UNIT REMOTE CONTROL PUMP STATION LOGIC DIAGRAM MODULE CONNECTIONS - PART 2
FS00-3-1.3	TYPICAL THREE UNIT REMOTE CONTROL PUMP STATION LOGIC DIAGRAM MODULE CONNECTIONS - PART 3
FS00-3-1.4	TYPICAL THREE UNIT REMOTE CONTROL PUMP STATION LOGIC DIAGRAM MODULE CONNECTIONS - PART 4
FS00-3-1.5	TYPICAL THREE UNIT REMOTE CONTROL PUMP STATION LOGIC DIAGRAM MODULE CONNECTIONS - PART 5 (CANCELLED)
FS00-4-1	6.6kV INSTALLATION - FEEDER PANEL >1000kVA POWER DIAGRAM
FS00-4-2	6.6kV INSTALLATION - MOTOR PANEL WITH BRUSH LIFTING FACILITIES POWER DIAGRAM
FS00-4-3	6.6kV INSTALLATION - MOTOR PANEL WITH BRUSH LIFTING FACILITIES CONTROL DIAGRAM
FS00-4-4	6.6kV INSTALLATION - FEEDER PANEL ≤1000kVA POWER DIAGRAM
FS00-4-5	6.6kV INSTALLATION - MOTOR PANEL WITHOUT BRUSH LIFTING FACILITIES POWER DIAGRAM
FS00-4-6	6.6kV INSTALLATION - MOTOR PANEL WITHOUT BRUSH LIFTING FACILITIES CONTROL DIAGRAM
FS00-4-7	6.6kV INSTALLATION SWITCHBOARD TYPICAL SINGLE LINE HV POWER DIAGRAM
FS00-5-1	LV INSTALLATION - INCOMER AND AUXILIARIES POWER DIAGRAM
FS00-5-2	LV INSTALLATION - MOTOR PANEL WITH BRUSH LIFTING FACILITIES POWER DIAGRAM
FS00-5-3	LV INSTALLATION - MOTOR PANEL WITH BRUSH LIFTING FACILITIES CONTROL DIAGRAM

ISSUE	DATE	GRID	REVISION	DRN	REC	APPD
F	06/2005		FS00-2-16 AND 17 ADDED			
E	03/2004		FS00-6-1 MOVED TO PART 2; FS00-1-1 NOW 1.1 & 1.2	AA	HdeV	KOG
D	06/2003		FS00-2-13, 14, 15, 5-1, 2, 3 AND 6-1 ADDED; PART 2 CREATED	TJT	RP	NHJ
C	11/2002		FS00-1-5.1, 5.2, 2-4.2 AND 4 SERIES ADDED; FS00-3-1.5 CANCELLED	TJT	RP	NHJ
B	10/2001		DRAWING LIST NUMBERS REVISED	AA	RP	NHJ

566
810

SURVEY BOOKS

VERTICAL DATUM NONE	DES CALC
COORDINATE SYS NONE	DES CHD KOG
DES REF	DRN TJT
	Q.C. CHD HdeV

NORTH POINT

CWS
ELECTRICAL & MECHANICAL ENGINEERING
ELECTRICAL DESIGN & STANDARDS DEVELOPMENT
37 Lemnos Street
Shenton Park WA 6008
Telephone : (08) 9380 7452
Mobile : 0419 967 520
PO Box 230
Wembley WA 6014
Facsimile : (08) 9380 7570

RECOMMENDED 21/08/2001
R PRITCHARD (SIGNED)
PRINCIPAL RGP ENG

RECOMMENDED 24/08/2001
N H JOHNSON (SIGNED)
SUPERVISING ELECTRICAL ENGINEER, IDB

APPROVED 24/08/2001
A KLITA (SIGNED)
PRINCIPAL ENGINEER, IDB

WATER CORPORATION

ELECTRICAL STANDARD DRAWING
MAJOR PUMP STATION
TABLE OF CONTENTS - PART 1

FILE
PROJECT
PLAN FS00-1-1.1
CAD
ISSUE F

ORIGINAL SHEET SIZE A1

MF 27.7.05

© THIS DRAWING IS THE PROPERTY OF THE WATER CORPORATION. IT SHALL NOT BE COPIED WITHOUT PERMISSION.

EMS DESIGN\PROJECTS\D04223W\CAD\FS00\FS0000100101F 14:48 07/07/2005 trainot0/WS11244